

CPA (Series) Digital Panel User Manual





Table Of Contents


<u>Screen Flow Diagram</u>	3
<u>Status Menu Tab</u>	4
<u>Status / Home</u>	5
<u>Status / All Inputs</u>	6
<u>Status / Schematic</u>	7
<u>Status / Charts - Temps</u>	8
<u>Status / Charts - Pressures</u>	9
<u>Status / Events</u>	10
<u>Status / Locked Outs</u>	11
<u>Settings Menu Tab</u>	12
<u>Settings / Date Time</u>	13
<u>Settings / About</u>	14
<u>Settings / Units of Measure</u>	15
<u>Settings / Diagnostics</u>	16
<u>Settings / User Options</u>	17
<u>Networking Tab</u>	18
<u>Communications Protocols</u>	19

Screen Flow Diagram

This is a general flow diagram of the screens available. The green colored "Main Screen" is the default starting screen. The blue "Sensing Options Screen" will only be available if logged in as an OEM user.



Status Menu Tab




This screen allows the operator to navigate between various status screens or to adjacent menu screens.

Status / Home




The "Home" screen is the default starting up screen. It is assumed that most facilities will have this screen up and running over the life of the compressor. The left dial indicates the low or gas input pressure and the right dial indicates the high or output pressure. Status about the running state of the compressor will be displayed on the Feedback Label. The bottom right Hours number tracks the total hours of operation the compressor has been running.

Status / All Inputs




The "All Inputs" screen is designed to give the user a complete picture of all the temperatures and pressures being monitored by the system. The Coolant In & Out gauges will have the word "Water" or "Air" depending on the system attached. The gauge on the right has two needles to indicate both the "Low" or inlet pressure and the "High" or outlet pressure. Bottom middle indicates the current draw on a single leg of the three phase power used to run the compressor motor. This reading isn't to show over all power consumption, merely to monitor if the motor is failing and not drawing any current. Note that other circuitry in the system draws power from this phase so when the system is idling it will show a low amount of power use. The averaging is from data over a 20 second period of time.

Status / Schematic




The "Schematic" screen is designed to give the general idea of how all the components are connected together. It also indicates the current temperature readings for the various parts of the system. To the left and right of the schematic are the "Low" or Inlet and "High" or outlet pressures.

Status / Charts - Temps




The charts screen has two modes. One is the temps reading mode and the alternate is pressure monitoring. When the temps mode is selected the time span is 5 minutes. Temp data is collected in 1 second intervals and is displayed with the newest data on the right hand side of the chart. The scales will auto adjust based on the data displayed.

Status / Charts - Pressures



The pressure monitoring mode has a time span of 2 seconds. The high and low pressures scales are independent and auto adjust based on captured data. A pause button is provided to allow closer examination of the charts.

Status / Events




27 - 07:26:08 — Running
27 - 07:26:05 — Starting
27 - 07:26:05 — Recover From Power Loss

CRYOMECH

The "Events" is an event logging window. It will hold up to 200 events but will not retain the events if there is a power loss. The format of the time stamping is Day - Time.


Status / Locked Outs

Lockouts	
24 Supply:	<input type="text" value="0"/>
3 Phase Power:	<input type="text" value="0"/>
Low Motor Current:	<input type="text" value="0"/>
Low Pressure - High:	<input type="text" value="0"/>
Low Pressure - Low:	<input type="text" value="0"/>
High Pressure - High:	<input type="text" value="0"/>
High Pressure - Low:	<input type="text" value="0"/>
Delta Pressure - High:	<input type="text" value="0"/>
Delta Pressure - Low:	<input type="text" value="0"/>
Coolant In - High:	<input type="text" value="0"/>
Coolant In - Low:	<input type="text" value="0"/>
Coolant Out - High:	<input type="text" value="0"/>
Coolant Out - Low:	<input type="text" value="0"/>
Oil Temp - High:	<input type="text" value="0"/>
Oil Temp - Low:	<input type="text" value="0"/>
Helium Temp - High:	<input type="text" value="0"/>
Helium Temp - Low:	<input type="text" value="0"/>

**CRYOMECH**

If the compressor experiences 6 or more errors in under an hour, it will shut down and begin a cooling timer. This screen will show you what issues have occurred over the last hour.


Settings Menu Tab



Settings / Date Time

Time Zone	
UTC - 5 Eastern Standard Time	
UTC	<input type="button" value="Set"/>


Date	Time
22 Mar 2016	13:00:43
<input type="text" value="22"/> <input type="text" value="03"/> <input type="text" value="2016"/>	<input type="text" value="13"/> <input type="text" value="00"/> <input type="text" value="40"/>
<input type="button" value="Set"/>	

**CRYOMECH**

Click on the text box below the portion of the date time that you wish to fix. After making proper adjustments, click the appropriate 'Set' button.

Settings / About

CRYOMECH	
315 - 455 - 2555 support@cryomech.com	
CODESYS V3.5 SP4+ Copyright 1994-2013 3S-Smart Software Solutions. GmbH	
Jmobile & Exor International S.p.A Version:	2.0 (0) - Build (265)
Main OS Version:	UN31HSXX60M0196
Cryomech Software Version:	1.192
Compressor SN:	TESTBOXA5J-160105K
Panel SN:	00001
Hours Of Operation:	0.1




All pertinent version info is stored here.

Settings / Units of Measure



The "Unit of Measures" screen is used to set what sorts of units we wish to display on the screen. For temperature you can select between Celsius, Fahrenheit or Kelvin. For pressure you can select between PSI, BAR & KPSA. Making a selection here will affect most other screens.

Settings / User Options



The image shows a user login interface on a light gray background. At the top, the text "User name:" is followed by a white rectangular input field. Below this, the text "Password:" is followed by another white rectangular input field. To the right of the password field is a small square checkbox with the text "Show password" next to it. Below the input fields are two red, rounded rectangular buttons with black outlines. The left button is labeled "Back" and the right button is labeled "Sign In". At the bottom of the interface, the word "CRYOMECH" is displayed in a large, bold, red, stylized font.

User name:




Password:

☐ Show password

CRYOMECH

Different operator levels provide access to special features. The general user should be logged in as "user" with no password.

Networking Tab

			
Gateway:		<input type="text" value="0.0.0.0"/>	
I.P. Address:		<input type="text" value="192.168.0.105"/>	
MAC ID:		<input type="text" value="AC:E0:10:AA:33:D9"/>	
Subnet Mask:		<input type="text" value="255.0.0.0"/>	
COM1: RS-232		COM2: RS-485	
Baud:	<input type="text" value="115200"/>	Baud:	<input type="text" value="115200"/>
Parity:	<input type="text" value="None"/>	Parity:	<input type="text" value="None"/>
Stop Bits:	<input type="text" value="1"/>	Stop Bits:	<input type="text" value="1"/>
Node ID:	<input type="text" value="0"/>	Node ID:	<input type="text" value="0"/>
<input type="button" value="Click To Save Serial Settings"/>		<input type="button" value="Click To Save Serial Settings"/>	

This page shows the IP data that gets assigned to the device by its network. By connecting to the compressor via serial port or by Ethernet it is possible to remotely monitor and operate the compressor. Compressors with a single DB-9 port only support RS-232. Compressors with two DB-9 ports also provide an RS-485 port.

Communications Protocols

The serial port uses Modbus RTU protocol and the Ethernet port uses ModbusTCP. More information about these protocols can be found here:

http://modbus.org/docs/PI_MBUS_300.pdf

The registers used for this protocol are as follows:

- 30,001 - Operating State
- 30,002 - Compressor Running
- 30,003 - Warning State
- 30,005 - Alarm State
- 30,007 - Coolant In Temp
- 30,009 - Coolant Out Temp
- 30,011 - Oil Temp
- 30,013 - Helium Temp
- 30,015 - Low Pressure
- 30,017 - Low Pressure Average
- 30,019 - High Pressure
- 30,021 - High Pressure Average
- 30,023 - Delta Pressure Average
- 30,025 - Motor Current
- 30,027 - Hours Of Operation
- 30,029 - Pressure Scale
- 30,030 - Temp Scale
- 30,031 - Panel Serial Number
- 30,032 - Model Major + Minor numbers
- 40,001 - Enable / Disable the compressor

The first two 'Input' registers and the only 'Holding' register are 16 bit integer registers and the rest of the input registers are in 32bit floating point format. The PLC code is written in Structured Text and the data stored is a REAL value. This means two Input registers are used to hold the value and the bytes will have to be rearranged before

converting them to floating format on the system. Below is a sample of C# code that successfully converts one of the registers to a floating point value. The Holding register 40,001 is used to signal the compressor to turn on and off.

```
byte[] data = (data returned)
byte[] arbyWorker = new byte[4];

arbyWorker[3] = data[2];
arbyWorker[2] = data[3];
arbyWorker[1] = data[0];
arbyWorker[0] = data[1];

float myFloat = BitConverter.ToSingle(arbyWorker, 0);
```

Values To Use:

Holding register 40001:

0x00FF - turn the compressor OFF

0x0001-Turn the compressor ON

Input Register 30001: (operating state)

0: Idling - ready to start

2: Starting

3: Running

5: Stopping

6: Error Lockout

7: Error

8: Helium Cool Down

9: Error-Power Related

16: Error Recovery

Input Register 30002: (Compressor Energized)

0: Off

1: On

Input Register 30003: (Warnings)

0: No warnings

-1: Coolant IN running High

-2: Coolant IN running Low

-4: Coolant OUT running High

-8: Coolant OUT running Low

-16: Oil running High

-32: Oil running Low

-64: Helium running High

-128: Helium running Low

-256: Low Pressure running High

-512: Low Pressure running Low

-1024: High Pressure running High

-2048: High Pressure running Low

-4096: Delta Pressure running High

-8192: Delta Pressure running Low

-131072: Static Pressure running High

-262144: Static Pressure running Low

-524288: Cold head motor Stall

Input Register 30005: (Errors)

0: No Errors

-1: Coolant IN High

-2: Coolant IN Low

-4: Coolant OUT High

-8: Coolant OUT Low

-16: Oil High

-32: Oil Low

-64: Helium High

-128: Helium Low

-256: Low Pressure High

-512: Low Pressure Low

-1024: High Pressure High

-2048: High Pressure Low

-4096: Delta Pressure High

-8192: Delta Pressure Low

-16384: Motor Current Low

-32768: Three Phase Error

-65536: Power Supply Error

-131072: Static Pressure High

-262144: Static Pressure Low

Input Register 30029: (Pressure)

0: PSI

1: Bar

2: KPA

Input Register 30030: (Temperature)

0: Fahrenheit

1: Celsius

2: Kelvin

Input Register 30032: Model Numbers

The upper 8 bits contain the Major model number and the lower 8 bits contain the Minor model number.

Major Model Numbers consist of

- 1: 800 Series
- 2: 900 Series
- 3: 1000 Series
- 4: 1100 Series
- 5: 2800 Series

Minor Model Numbers consist of:

- | | |
|--------|--------|
| 1: A1 | 13: 07 |
| 2: 01 | 14: H7 |
| 3: 02 | 15: I7 |
| 4: 03 | 16: 08 |
| 5: H3 | 17: 09 |
| 6: I3 | 18: 9C |
| 7: 04 | 19: 10 |
| 8: H4 | 20: 1I |
| 9: 05 | 21: 11 |
| 10: H5 | 22: 12 |
| 11: I6 | 23: 13 |
| 12: 06 | 24: 14 |

Example: A 289C compressor will give a Major of 5 and a Minor of 18.

15 Pin Remote Control

The 15 pin control port documentation is available on request.